


# User's Manual



Before operating the Monitor, please read this manual thoroughly and retain it for future reference.



- ①
- ②
- ③
- ④
- ⑤
- ⑥
- ⑦
- ⑧
- ⑨
- ⑩



- |                         |                                       |
|-------------------------|---------------------------------------|
| 1. Power Indicate Light | 6. MENU                               |
| 2. R/C Window           | 7. Positive Increase                  |
| 3. Power                | 8. VGA Input                          |
| 4. V1/V2/VGA Change     | 9. USB Input for Touch Screen Control |
| 5. Negative Decrease    | 10. DC IN Jack                        |

**CAUTION:**


For your safety, please rotate the angle of the display or turn off the display while driving.

**SPECIAL STATEMENT:**

LCD may have a few bright dots, which is normal for the matrix display technology, and doesn't indicate defects of faults

**NOTICE:**


- Please operate instruction manual completely before use;
- The unit is manufactured with precision elements pay attention to protection against dampness;
- Prevent the hard object from scratching LCD surface;
- High voltage inside non-technical authorized person is not allowed to dismantle the unit.



**REMOTE CONTROL**

1. Power
2. V1/V2/VGA Change
3. Positive Increase
4. Menu
5. Negative Decrease
6. Reset

**Connection**



**SPECIFICATIONS:**

- Display Size: 9.2 inch (16:9)
- Resolution: 800\*R.G.B.\*480
- Dual Video Inputs, 1 Audio Input (VGA Input Optional)
- System: PAL & NTSC Auto Switching
- Power Supply: DC +12V
- Built in Speaker
- All Functions can be Controlled by Remote Control
- Touch Screen (Optional)
- Wide View Angle

**IF YOUR MONITOR IS WITH TOUCH SCREEN, PLEASE INSTALL THE DRIVER FROM THE DISC BEFORE USING**

**P.S.: PLEASE DO NOT CONNECT THE USB CABLE TO THE MONITOR BEFORE INSTALLING THE DRIVER.**